

MyCableMart.com

Your Home Theatre Connectivity Experts

6224 Bury Dr, Eden Prairie MN 55346 P. 952-486-8736

6FT USB 2.0 CERTIFIED 480MBPS TYPE A MALE TO MINI-B/5-PIN GOLD PLATED W/FERRITE



Lengths Available:

Colors Available:			
Part Numbers this model:	MO-5448		
Sales Category:	USB Cables	Wire Gauge (AWG):	24 AWG, 28 AWG
Connector A:	USB Standard Type A Male	Specification:	USB 2.0
Connector B:	USB Standard Type A Male	Number Ports:	N/A
Export Tariff Code (HST):	8544422000	Transfer Rate:	480Mbps
Feature / Style:	Data Transfer and Charge	Images Length/Size Shown:	6 FT
# Positions:		Shielding:	Shielded
Convert From/To:		Type:	

Connects your computer to any USB device with Mini B 5 pin female port. This cable allows you to connect peripherals such as digital cameras, Video cameras, smart phones, MP3 players, and storage drives. It is USB 2.0 compatible and supports USB speed up to 480Mbps.

Connectors: Type A Male to Mini B 5 pin Male

Color: Black

Ferrite Core at MINI-USB Connector End

Gold Plated Conductors and connector shell

Compatibility List

Note: Additional devices may also be compatible. This is NOT an exhaustive list.

Sony Cameras

Digital Camera Mavica MVC-FD92, Mavica MVC-FD97, Mavica MVC-FD100, Mavica MVC-FD200 , Mavica MVC-CD200, Mavica MVC-CD250, Mavica MVC-CD300, Mavica MVC-CD400, Cyber-shot DSC-U10, Cyber-shot DSC-P1, Cyber-shot DSC-P2, Cyber-shot DSC-P5, Cyber-shot DSC-P7, Cyber-shot DSC-P8, Cyber-shot DSC-P9, Cyber-shot DSP-P5, Cyber-shot DSP-P9, Cyber-shot DSC-P20, Cyber-shot DSC-P30, Cyber-shot DSC-P31, Cyber-shot DSC-P50, Cyber-shot DSC-P51, Cyber-shot DSC-P71, Cyber-shot, DSC-S75, Cyber-shot DSC-S85, Cyber-shot DSC-F707, Cyber-shot DSC-F717, Cyber-shot DSC-U10, DCR-PC9, Sony MP3 - Net MD Walkman, MZ-NE410, MZ-N505GOLD, MZ-N707BLACK, MZ-N707BLUE, MZ-S1, S2 Sports NET MD

Sony Camcorders

CCD-TRV608 DCR-HC85E DCR-PC330E DCR-TRV250 DCR-DVD7E DCR-HC90E DCR-PC350 DCR-TRV250E DCR-DVD505E DCR-HC1000 DCR-PC350E DCR-TRV260 DCR-DVD100 DCR-IP1 DCR-TRV14E DCR-TRV265E DCR-DVD100E DCR-IP1E DCR-TRV17 DCR-TRV270E DCR-DVD101 DCR-IP7BT DCR-TRV18 DCR-TRV285E DCR-DVD101E DCR-IP7E DCR-TRV19 DCR-TRV330 DCR-DVD200 DCR-IP55 DCR-TRV19E DCR-TRV340 DCR-DVD200E DCR-IP55E DCR-TRV22 DCR-TRV340E DCR-DVD201 DCR-IP220 DCR-TRV22E DCR-TRV350 DCR-DVD201E DCR-IP220E DCR-TRV25 DCR-TRV355E DCR-DVD203E DCR-PC9 DCR-TRV25E DCR-TRV360 DCR-DVD300 DCR-PC53E DCR-TRV27 DCR-TRV460 DCR-HC14E DCR-PC55E DCR-TRV30 DCR-TRV460E DCR-HC18E DCR-PC101 DCR-TRV33 DCR-TRV480E DCR-HC19E DCR-PC101E DCR-TRV33E DCR-TRV530 DCR-HC20 DCR-PC103E DCR-TRV38 DCR-TRV730 DCR-HC20E DCR-PC105 DCR-TRV39 DCR-TRV740 DCR-HC22E DCR-PC105E DCR-TRV40E DCR-TRV740E DCR-HC30 DCR-PC106E DCR-TRV50 DCR-TRV830 DCR-HC30E DCR-PC107E DCR-TRV50E DCR-TRV840 DCR-HC32E DCR-PC109 DCR-TRV60E DCR-TRV950DCR-HC39E DCR-PC109E DCR-TRV70 HDR-HC1E DCR-HC40 DCR-PC110 DCR-TRV80 DPP-EX50 DCR-HC40E DCR-PC115 DCR-TRV80E DPP-FP30 DCR-HC42E DCR-PC120BT DCR-TRV140 DPP-FP50 DCR-HC65 DCR-PC120E DCR-TRV240 DCR-HC85 DCR-PC330 DCR-TRV245E

Canon

Compare to Canon IFC-300PCU USB Cables

Digital IXUS 500, IXUS 430, IXUS 300 (S300 ELPH), ZR90, ZR45mc, ZR50mc, ZR65mc, ZR70mc OPTURA 300, OPTURA Xi, OPTURA 20 Elura 70, Elura 65, Elura 60 EOS 10D, EOS Digital Rebel Powershot S500, S410, S400, S330, S300, S30, S40, S45, SD100, SD10, SD110, A300, A200, A100, A10, A20, A30, A40, A60, A70, A80, G5, G3, Pro 1, S1 IS

Olympus

Compare to Olympus CB-USB4 USB Cable

Stylus Digital 300, 400, 410 C-50 Zoom, C-720 Ultra Zoom, C-730 Ultra Zoom, C-4000 Zoom,C-5050 Zoom,D-380 Stylus 300 Digital, Stylus 400 Digital, C-8080 Wide Zoom, C-5060 Wide Zoom, C-5000 Zoom, C-5060 Zoom, C-5050 Zoom, C-50 Zoom, C-4000 Zoom,C-750 Ultra Zoom, C-770 Ultra Zoom, C-765 Ultra Zoom, C-740 Ultra Zoom, C-730 Ultra Zoom, C-720 Ultra Zoom, D-580 Zoom, D-575 Zoom, D-565 Zoom, D-560 Zoom, D-550 Zoom, D-540 Zoom, D-520 Zoom, D-390, D-380

HP (Hewlett-Packard)

Compare to HP #8121-0637/8121-0721 USB Cables

Hewlett Packard Photosmart 120, Photosmart 120CSE, Photosmart 120V, Photosmart 318, Photosmart 318xi, Photosmart 318se, Photosmart 320, Photosmart 320xi, Photosmart 612, Photosmart 612Cxi, Photosmart 612xi, Photosmart 620xi, Photosmart 620v, Photosmart 715, Photosmart 715Cxi, Photosmart 850xi, Photosmart 720v, Photosmart 720xi, Photosmart 720

JVC

JVC GR-DV3000U, GR-DV2000U, GR-DVM96U, GR-DVL920U, GR-DVM76U, GR-DVP3U, GR-DVP7U, GR-DVL820U, GR-DVL725U, GR-DVL720U, GR-DVL520U, GR-DVL915U, GR-DVL815U, GR-DVL510U, GRD93US, GRD90US, GRD72, GRD70US, GR-DVL510U, GR-DVL815U, GR-DVL915U, GR-DVL512U, GR-DVL520U, GR-DVL720U, GR-DVL725U, GR-DVL817U, GR-DVL820U, GR-DVL920U, GR-DVM96U

Panasonic

Panasonic Lumix DMC-LC5K , DMC-LC5S , DMC-LC40K , DMC-LC40S , DMC-F7 , DMC-LC20S ,DMC-LC20K ,DMC-FZ1 ,DMC-FZ1S, DMC-FZ10, DMC-FZ10K, DMC-LC33, DMC-L33 PV-GS70, PV-GS50, PV-GS50S, PV-DV203, SV-AV100

Nikon

Compare to Nikon #UC-E5 USB Cable

Nikon CoolPix 2000 , D100

Samsung

Samsung Digimax 201, Digimax 200, Digimax 230, Digimax 340, Digimax 410, SCD180, SCD23, SCD24, SCD27, SCD29, SCD33, SCD34, SCD39, SCD5000, SCD590, SCD86, SCL770, SCL870

AEGUS

AEGUS DC3550, DC3510, DC3500

ARCHOS

ARCHOS Jukebox , Multimedia 10 ,Jukebox Multimedia 20 , Jukebox FM Recorder 20 , ONDIO

SHARP

SHARP VL-NZ155U , VL-NZ150U , VL-NZ105U , VL-NZ100U

Casio

QV-4000, QV-R40

Fuji

FinePix S5000

Motorola

Motorola MPX200 / RAZR V3 / V3C / SLVR L7 / L6 / PEBL U6 / V360 / C331 / C332 / C333 / C350 / v220 / v180 / c650 / c330 / c370

BlackBerry

BlackBerry 6210, 6220, 6230, 6280, 6510, 7100g, 7100r, 7100t, 7100v, 7100x, 7210, 7230, 7250, 7270, 7280, 7290, 7510, 8700, 8700c, 7130, 7130e, 7105t, & 7520

Hitachi

DZMV380A, DZMV350A, DZMV230A, DZMV270A, DZMV200A

Konica

KD-220Z

Minolta

DiIMAGE E223, G400, A-series (A1/A2)

Creative

Jukebox 2, Jukebox 2LX, Jukebox 3, Jukebox Zen, Jukebox Zen 2.0 20gb, Jukebox Zen 2.0 60gb,Jukebox Zen NX, Jukebox Zen Xtra,MuVo2 1.5GB, MuVo2 4GB, MuVo2 X-Trainer

Toshiba

PDR-M700, PDR-M500, PDR-T10